

5.2.10.41. UnboltDoor Command

This command causes the lock device to unlock the door without pulling the latch. This command includes an optional code for the lock. The door lock MAY require a code depending on the value of the [RequirePINForRemoteOperation](#) attribute.

NOTE

If the attribute `AutoRelockTime` is supported, the lock will transition to the locked state when the auto relock time has expired.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	PINCode	octstr				[COTA & PIN]

5.2.10.41.1. PINCode Field

See [Section 5.2.10.1.1, “PINCode Field”](#).

5.2.10.42. SetAliroReaderConfig Command

This command allows communicating an Aliro Reader configuration, as defined in [\[Aliro\]](#), to the lock.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	SigningKey	octstr	32			M
1	Verification-Key	octstr	65			M
2	GroupIdentifier	octstr	16			M
3	GroupResolvingKey	octstr	16			ALBU

5.2.10.42.1. SigningKey Field

This field SHALL indicate the signing key component of the Reader’s key pair.

5.2.10.42.2. VerificationKey Field

This field SHALL indicate the verification key component of the Reader’s key pair. This SHALL be an uncompressed elliptic curve public key as defined in section 2.3.3 of [SEC 1](#).

5.2.10.42.3. GroupIdentifier Field

This field SHALL indicate the reader group identifier for the lock.

5.2.10.42.4. GroupResolvingKey Field

This field SHALL indicate the group resolving key for the lock.