

5.2.11.2.1. DoorState Field

This field SHALL indicate the new door state for this door event.

5.2.11.3. LockOperation Event

The door lock server sends out a LockOperation event when the event is triggered by the various lock operation sources.

The data of this event SHALL contain the following information:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	LockOperationType	LockOperationTypeEnum	all			M
1	OperationSource	OperationSourceEnum	all			M
2	UserIndex	uint16	all	X		M
3	FabricIndex	fabric-idx	all	X		M
4	SourceNode	node-id	all	X		M
5	Credentials	list[CredentialStruct]	1 to NumberOfCredentialsSupportedPerUser	X		[USR]

- If the door lock server supports the [Unbolt Door](#) command, it SHALL generate a LockOperation event with LockOperationType set to Unlock after an Unbolt Door command succeeds.
- If the door lock server supports the [Unbolting](#) feature and an Unlock Door command is performed, it SHALL generate a LockOperation event with LockOperationType set to Unlatch when the unlatched state is reached and a LockOperation event with LockOperationType set to Unlock when the lock successfully completes the unlock → hold latch → release latch and return to unlock state operation.
- If the command fails during holding or releasing the latch but after passing the unlocked state, the door lock server SHALL generate a LockOperationError event with LockOperationType set to Unlatch and a LockOperation event with LockOperationType set to Unlock.
 - If it fails before reaching the unlocked state, the door lock server SHALL generate only a LockOperationError event with LockOperationType set to Unlock.
- Upon manual actuation, a door lock server that supports the [Unbolting](#) feature:
 - SHALL generate a LockOperation event of LockOperationType Unlatch when it is actuated from the outside.
 - MAY generate a LockOperation event of LockOperationType Unlatch when it is actuated