

if the PositionAware feature is supported:

- CurrentPositionLiftPercent100ths attribute SHALL be 100.00%.
- CurrentPositionLiftPercentage attribute SHALL be 100%.
- CurrentPositionTiltPercent100ths attribute SHALL be 100.00%.
- CurrentPositionTiltPercentage attribute SHALL be 100%.

if the AbsolutePosition feature is supported:

- CurrentPositionLift attribute SHALL be equal to the InstalledClosedLimitLift attribute.
- CurrentPositionTilt attribute SHALL be equal to the InstalledClosedLimitTilt attribute.

5.3.7.3. StopMotion Command

Upon receipt of this command, the window covering will stop any adjusting to the physical tilt and lift/slide that is currently occurring. The server attributes supported SHALL be updated as follows:

- TargetPositionLiftPercent100ths attribute will be set to CurrentPositionLiftPercent100ths attribute value.
- TargetPositionTiltPercent100ths attribute will be set to CurrentPositionTiltPercent100ths attribute value.

5.3.7.4. GoToLiftPercentage Command

This command is used to set the target lift position of the window covering to the percentage value specified in the command.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	LiftPercent100thsValue	percent100ths	desc			M

Upon receipt of this command, the server will adjust the window covering to the lift/slide percentage specified in the payload of this command.

If the command includes LiftPercent100thsValue, then TargetPositionLiftPercent100ths attribute SHALL be set to LiftPercent100thsValue. Otherwise the TargetPositionLiftPercent100ths attribute SHALL be set to LiftPercentageValue * 100.

If a client includes LiftPercent100thsValue in the command, the LiftPercentageValue SHALL be set to LiftPercent100thsValue / 100, so a legacy server which only supports LiftPercentageValue (not LiftPercent100thsValue) has a value to set the target position.

If the server does not support the PositionAware feature, then a zero percentage SHALL be treated as a UpOrOpen command and a non-zero percentage SHALL be treated as an DownOrClose command. If the device is only a tilt control device, then the command SHOULD be ignored and a UNSUPPORTED_COMMAND status SHOULD be returned.