

5.3.7.5. GoToTiltPercentage Command

This command is used to set the target tilt position of the window covering to the percentage value specified in the command.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	TiltPercent100thsValue	percent100ths	desc			M

Upon receipt of this command, the server will adjust the window covering to the tilt percentage specified in the payload of this command.

If the command includes TiltPercent100thsValue, then TargetPositionTiltPercent100ths attribute SHALL be set to TiltPercent100thsValue. Otherwise the TargetPositionTiltPercent100ths attribute SHALL be set to TiltPercentageValue * 100.

If a client includes TiltPercent100thsValue in the command, the TiltPercentageValue SHALL be set to TiltPercent100thsValue / 100, so a legacy server which only supports TiltPercentageValue (not TiltPercent100thsValue) has a value to set the target position.

If the server does not support the PositionAware feature, then a zero percentage SHALL be treated as a UpOrOpen command and a non-zero percentage SHALL be treated as an DownOrClose command. If the device is only a tilt control device, then the command SHOULD be ignored and a UNSUPPORTED_COMMAND status SHOULD be returned.

5.4. Closure Control Cluster

This cluster provides an interface for controlling a Closure.

5.4.1. Revision History

The global ClusterRevision attribute value SHALL be the highest revision number in the table below.

Rev	Description
1	Initial revision

5.4.2. Classification

Hierarchy	Role	Scope	PICS Code
Base	Application	Endpoint	CLCTRL

5.4.3. Cluster ID