

Value	Name	Summary	Conformance
2	WaitingForMotion	Closure is waiting before a motion (e.g. pre-heat, pre-check)	M
3	Error	Closure is in an error state	M
4	Calibrating	Closure is currently calibrating its Opened and Closed limits to determine effective physical range	CL
5	Protected	Some protective measures are activated to prevent damage to the closure. Commands MAY be rejected.	PT
6	Disengaged	Closure has a disengaged element preventing any actuator movements	MO
7	SetupRequired	Movement commands are ignored since the closure is not operational and requires further setup and/or calibration	M

5.4.6.4. ClosureErrorEnum Type

This data type is derived from enum8.

The following ranges are reserved for general and manufacturer specified closure errors.

Value	Name	Summary
0x00 to 0x7F	GeneralErrors	Generally applicable values for error, defined herein
0x80 to 0xBF	ManufacturerError	Vendor specific errors

The manufacturer-specific error definitions SHALL NOT duplicate the general error definitions. Such manufacturer-specific error definitions SHALL be scoped in the context of the Vendor ID present in the Basic Information cluster.

The general closure error values are defined in the table below.