

- cluster, as described in [Section 5.4.4, “Association Between Closure Control and Closure Dimension Clusters”](#).
- The Stop command.

5.4.7.5. OverallTargetState Attribute

This attribute SHALL indicate the TargetPosition, TargetLatch and/or TargetSpeed values, whichever are applicable according to the feature flags set.

This attribute SHALL be null, if the state is unknown. For example after a reboot.

5.4.7.6. LatchControlModes Attribute

This attribute SHALL specify whether the latch mechanism can be latched or unlatched remotely.

5.4.8. Commands

The table below lists the changes relative to the Operational State cluster for the commands. A blank field indicates no change.

ID	Name	Direction	Response	Access	Conformance
0x00	Stop	client ⇒ server	Y	O	!IS
0x01	MoveTo	client ⇒ server	Y	O T	M
0x02	Calibrate	client ⇒ server	Y	M T	CL

5.4.8.1. Stop Command

- On receipt of this command, the closure SHALL stop its movement as fast as the closure is able too.
- If the server’s [MainState](#) attribute has one of the following values:
- Moving
 - WaitingForMotion
 - Calibrating

then any motions SHALL be stopped and the [MainState](#) attribute SHALL be set to Stopped.

A status code of SUCCESS SHALL always be returned, regardless of the value of the [MainState](#) attribute when this command is received.

5.4.8.2. MoveTo Command

On receipt of this command, the closure SHALL operate to update its position, latch state and/or motion speed.