

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Position	TargetPositionEnum			desc	O.a+
1	Latch	bool			desc	O.a+
2	Speed	ThreeLevelAutoEnum			Auto	O.a+

The rationale behind defining the conformance as being purely optional in the table above is to ensure that commands containing one or more fields related to unsupported features are still accepted, rather than being rejected outright. For example, if a simple client, which is not able to determine the capabilities of the server, invokes a command that includes both position and speed, a server that does not support the speed feature would simply ignore the speed field while still adjusting its position as requested.

5.4.8.2.1. Position Field

This field SHALL indicate the position where the closure is moving to, as defined in the [TargetPositionEnum](#).

If the field is present but its value is not within constraints, then:

- If the Positioning (PS) feature is not supported, the value of this field SHALL be ignored.
- If the Positioning (PS) feature is supported, a status code of CONSTRAINT_ERROR SHALL be returned.

If the Positioning (PS) feature is supported and the Position field is not present, the closure SHALL use the value of the Position field in the OverallTargetState attribute as the fallback. If the Position field in the OverallTargetState attribute is NULL, the position is unknown and the fallback is not applicable; in this case the field SHALL be ignored and the closure SHALL NOT change its position.

5.4.8.2.2. Latch Field

This field SHALL indicate the desired latching state of the closure, as defined in the [OverallCurrentStateStruct Latch Field](#).

If the field is present but its value is not within constraints, then:

- If the MotionLatching (LT) feature is not supported, the value of this field SHALL be ignored.
- If the MotionLatching (LT) feature is supported, a status code of CONSTRAINT_ERROR SHALL be returned.

If the MotionLatching (LT) feature is supported and the Latch field is not present, the closure SHALL use the value of the Latch field in the OverallTargetState attribute as the fallback. If the Latch field in the OverallTargetState attribute is NULL, the latch state is unknown and the fallback is not applicable, in this case, the field SHALL be ignored and the closure SHALL NOT change its latch state.