

5.5.8.1.1. Position Field

This field SHALL indicate the position where the closure is moving to.

If the field is present but its value is not within constraints, then:

- If the Positioning (PS) feature is not supported, the value of this field SHALL be ignored.
- If the Positioning (PS) feature is supported, a status code of CONSTRAINT_ERROR SHALL be returned.

If the Positioning (PS) feature is supported and the Position field is not present, the closure SHALL use the value of the Position field in the TargetState attribute as the fallback. If the Position field in the TargetState attribute is NULL, the position is unknown and the fallback is not applicable, in this case the field SHALL be ignored and the closure SHALL NOT change its position.

When the closure supports the Positioning(PS) feature:

If a new position value is requested, the closure SHALL set the Position field of the [TargetState](#) attribute to the nearest valid position (an integer multiple of the Resolution attribute), whether by rounding the requested value or using it directly if already valid, and then initiate the motion procedure.

5.5.8.1.2. Latch Field

This field SHALL indicate the desired latching state of the closure, as defined in the [OverallCurrentStateStruct Latch Field](#).

If the field is present but its value is not within constraints, then:

- If the MotionLatching (LT) feature is not supported, the value of this field SHALL be ignored.
- If the MotionLatching (LT) feature is supported, a status code of CONSTRAINT_ERROR SHALL be returned.

If the MotionLatching (LT) feature is supported and the Latch field is not present, the closure SHALL use the value of the Latch field in the TargetState attribute as the fallback. If the Latch field in the TargetState attribute is NULL, the latch state is unknown and the fallback is not applicable, in this case, the field SHALL be ignored and the closure SHALL NOT change its latch state.

If the server supports the MotionLatching (LT) feature, it SHALL either fulfill the latch request and update [TargetState.Latch](#), or - if the ["LatchControlModes"](#) attribute specifies that manual intervention is required to latch - respond with INVALID_IN_STATE and remain in its current state.

5.5.8.1.3. Speed Field

This field SHALL indicate a desired overall speed of motion, as defined in the [ThreeLevelAutoEnum](#).

If the field is present but its value is not within constraints, then:

- If the Speed(SP) feature is not supported, the value of this field SHALL be ignored.
- If the Speed(SP) feature is supported, a status code of CONSTRAINT_ERROR SHALL be returned.