

5.5.8.2. Step Command

This command is used to move a dimension of the closure to a target position by a number of steps.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Direction	StepDirectionEnum				M
1	NumberOfSteps	uint16	min 1			M
2	Speed	ThreeLevelAutoEnum	desc		Auto	[SP]

5.5.8.2.1. Direction Field

This field SHALL indicate whether the Position field of the [TargetState](#) attribute must be:

- Increased toward 100.00%.
- Decreased toward 0.00%.

5.5.8.2.2. NumberOfSteps Field

This field SHALL indicate the number of steps by which the position should be changed. The size of one step, expressed in percent100ths, is determined by the ["StepValue"](#) attribute.

5.5.8.2.3. Speed Field

This field SHALL indicate the desired speed of motion.

5.5.8.2.4. Effect on Receipt

Upon receipt of this command:

- If this command is received while the Latch field of the CurrentState attribute is True (Latched), a status code of INVALID_IN_STATE SHALL be returned.
- If this command is received while the MainState attribute of the [Closure Control Cluster](#) that is [associated](#) with this cluster has any of the following values:
 - Disengaged
 - Protected
 - Calibrating
 - SetupRequired
 - Error

then a status code of INVALID_IN_STATE SHALL be returned.

- Otherwise, the server SHALL respond with a status code of SUCCESS and the TargetState attribute value SHALL be changed as follows: