

(2550), 26.00C (2600), 26.50C (2650), etc.

8.2.5.5. SelectedTemperatureLevel Attribute

This attribute SHALL represent the currently selected temperature level setting of the server. This attribute SHALL be the positional index of the list item in the SupportedTemperatureLevels list that represents the currently selected temperature level setting of the server.

8.2.5.6. SupportedTemperatureLevels Attribute

This attribute SHALL represent the list of supported temperature level settings that may be selected via the TargetTemperatureLevel field in the SetTemperature command. Each string is readable text that describes each temperature level setting in a way that can be easily understood by humans. For example, a washing machine can have temperature levels like "Cold", "Warm", and "Hot". Each string is specified by the manufacturer.

Each item in this list SHALL represent a unique temperature level. Each entry in this list SHALL have a unique value. The entries in this list SHALL appear in order of increasing temperature level with list item 0 being the setting with the lowest temperature level.

8.2.6. Commands

ID	Name	Direction	Response	Access	Conformance
0x00	SetTemperature	client ⇒ server	Y	O	M

8.2.6.1. SetTemperature Command

This command is used to set the temperature setpoint.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	TargetTemperature	temperature	desc			TN
1	TargetTemperatureLevel	uint8	desc			TL

8.2.6.1.1. TargetTemperature Field

This field SHALL specify the desired temperature setpoint that the server is to be set to.

The TargetTemperature SHALL be from MinTemperature to MaxTemperature inclusive. If the Step attribute is supported, TargetTemperature SHALL be such that (TargetTemperature - MinTemperature) % Step == 0.