

| Value | Name          | Summary                                                    | Conformance |
|-------|---------------|------------------------------------------------------------|-------------|
| 0     | <b>Low</b>    | Provides a low dryness level for the selected mode         | M           |
| 1     | <b>Normal</b> | Provides the normal level of dryness for the selected mode | M           |
| 2     | <b>Extra</b>  | Provides an extra dryness level for the selected mode      | M           |
| 3     | <b>Max</b>    | Provides the max dryness level for the selected mode       | M           |

### 8.9.5. Attributes

| ID     | Name                   | Type                   | Constraint | Quality | Fallback | Access | Conformance |
|--------|------------------------|------------------------|------------|---------|----------|--------|-------------|
| 0x0000 | SupportedDrynessLevels | list[DrynessLevelEnum] | 1 to 4     |         |          | R V    | M           |
| 0x0001 | SelectedDrynessLevel   | DrynessLevelEnum       | desc       | X       |          | RW VO  | M           |

#### 8.9.5.1. SupportedDrynessLevels Attribute

This attribute SHALL indicate the list of supported dryness levels available to the appliance in the currently selected mode. The dryness level values are determined by the manufacturer. At least one dryness level value SHALL be provided in the SupportedDrynessLevels list. The list of dryness levels MAY change depending on the currently-selected Laundry Dryer mode.

#### 8.9.5.2. SelectedDrynessLevel Attribute

This attribute SHALL indicate the currently-selected dryness level and it SHALL be the index into the SupportedDrynessLevels list of the selected dryness level.

If an attempt is made to write this attribute with a value other than null or a value contained in SupportedDrynessLevels, a CONSTRAINT\_ERROR response SHALL be sent as the response. If an attempt is made to write this attribute while the device is not in a state that supports modifying the dryness level, an INVALID\_IN\_STATE error SHALL be sent as the response. A value of null SHALL indicate that there will be no dryness level setting for the current mode.