

enable it permanently.

9.3.9.2.2. MinimumChargeCurrent Field

This field SHALL indicate the minimum current that can be delivered by the EVSE to the EV in trickle mode. The EVSE current limit can be advertised to an EV in 0.6A steps.

The value of the [MinimumChargeCurrent](#) attribute SHALL be set to the value of this field (see [Section 9.3.8.7, “MinimumChargeCurrent Attribute”](#) for further details).

9.3.9.2.3. MaximumChargeCurrent Field

This field SHALL indicate the maximum current that can be delivered by the EVSE to the EV. The EVSE current limit can be advertised to an EV in 0.6A steps.

The value of the this field SHALL be stored by the EVSE to determine the value of [MaximumChargeCurrent](#) attribute. For example, if the [UserMaximumChargeCurrent](#) attribute is adjusted below then this value, and then later adjusted above this value, the resulting [MaximumChargeCurrent](#) attribute will be limited to this value.

9.3.9.2.4. Effect on Receipt

On receipt of this command, this SHALL allow the EVSE to charge the EV until the specified timestamp within the current limits specified in the fields of the command.

If there is currently an error present on the EVSE, or Diagnostics are currently active, then the command SHALL be ignored and a response with a status of FAILURE SHALL be returned.

If successful, the [SupplyState](#) attribute SHALL be set to ChargingEnabled (if previously Disabled) or Enabled (if previously DischargingEnabled), and a response with status of SUCCESS SHALL be returned.

The timestamp indicated in the [ChargingEnabledUntil](#) attribute SHALL be updated to the timestamp of the ChargingEnabledUntil field if the command is successful.

If the ChargingEnabledUntil is null (i.e. should be permanently enabled), then the EVSE should enable charging indefinitely.

If the ChargingEnabledUntil time is not null, then when this time expires then the EVSE SHALL stop charging and SHALL update the [State](#) attribute to indicate it is no longer charging, and SHALL update the [SupplyState](#) attribute to Disabled (if [DischargingEnabledUntil](#) is also in the past) or DischargingEnabled (if [DischargingEnabledUntil](#) is in the future or null).

9.3.9.3. EnableDischarging Command

Upon receipt, this SHALL allow a client to enable the discharge of an EV, and to provide or update the maximum discharge current.