

ID	Name	Type	Constraint	Quality	Fallback	Conformance
2	Reason	Energy-Transfer-StoppedReasonEnum	all			M
4	Energy-Transferred	energy-mWh	min 0			M
5	EnergyDischarged	energy-mWh	min 0			V2X

9.3.10.4.1. SessionID Field

This field SHALL indicate the value of the [SessionID](#) attribute prior to the energy transfer stopping.

9.3.10.4.2. State Field

This field SHALL indicate the value of the [State](#) attribute prior to the energy transfer stopping.

9.3.10.4.3. Reason Field

This field SHALL indicate the reason why the energy transferred stopped.

9.3.10.4.4. EnergyTransferred Field

This field SHALL indicate the amount of energy transferred from the EVSE to the EV since the previous EnergyTransferStarted event, in mWh.

9.3.10.4.5. EnergyDischarged Field

This field SHALL indicate the amount of energy transferred from the EV to the EVSE since the previous EnergyTransferStarted event, in mWh.

9.3.10.5. Fault Event

If the EVSE detects a fault it SHALL generate a Fault Event. The SupplyState attribute SHALL be set to DisabledError and the type of fault detected by the EVSE SHALL be stored in the FaultState attribute.

This event SHALL be generated when the FaultState changes from any error state. i.e. if it changes from NoError to any other state and if the error then clears, this would generate 2 events.

It is assumed that the fault will be cleared locally on the EVSE device. When all faults have been cleared, the EVSE device SHALL set the FaultState attribute to NoError and the SupplyState attribute SHALL be set back to its previous state.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	SessionID	uint32	all	X		M