

If the value of [EnergyBalances](#) changes after an update, the device SHALL migrate the value of the [CurrentEnergyBalance](#) attribute to the index which the manufacturer specifies most closely matches the previous value, while preserving extreme preferences as follows:

1. If the previous value of [CurrentEnergyBalance](#) was zero, indicating a total preference for the priority specified by the first element in [EnergyPriorities](#), the new value of [CurrentEnergyBalance](#) SHALL also be zero.
2. If the previous value of [CurrentEnergyBalance](#) was the index of the last [BalanceStruct](#) in the previous value of [EnergyBalances](#), indicating a total preference for the priority specified by the last element in [EnergyPriorities](#), the new value of [CurrentEnergyBalance](#) SHALL be the index of the last element in the updated value of [EnergyBalances](#).

#### 9.7.6.3. EnergyPriorities Attribute

This attribute SHALL indicate two extremes for interpreting the values in the [EnergyBalances](#) attribute. These two priorities SHALL be in opposition to each other; e.g. Comfort vs. Efficiency or Speed vs. WaterConsumption.

If the value of [EnergyPriorities](#) changes after an update to represent a new balance between priorities, the value of the [CurrentEnergyBalance](#) attribute SHALL be set to its default.

#### 9.7.6.4. LowPowerModeSensitivities Attribute

This attribute SHALL indicate a list of [BalanceStructs](#), each representing a condition or set of conditions for the device to enter a low power mode.

This SHALL contain at least two [BalanceStructs](#).

Each [BalanceStruct](#) SHALL have a [Step](#) field larger than the [Step](#) field on the previous [BalanceStruct](#) in the list.

#### 9.7.6.5. CurrentLowPowerModeSensitivity Attribute

This attribute SHALL indicate the current preference of the user for determining when the device should enter a low power mode. The value of this attribute is the index, 0-based, into the [LowPowerModeSensitivities](#) attribute for the currently selected preference.

If an attempt is made to set this attribute to an index outside the maximum index for [LowPowerModeSensitivities](#), a response with the status code `CONSTRAINT_ERROR` SHALL be returned.

If the value of [LowPowerModeSensitivities](#) changes after an update, the device SHALL migrate the value of the [LowPowerModeSensitivity](#) attribute to the index which the manufacturer specifies most closely matches the previous value.

## 9.8. Device Energy Management Mode Cluster

This cluster is derived from the Mode Base cluster and defines additional mode tags and name-spaced enumerated values for Device Energy Management devices.