

networks as the user's preferred network via the [PreferredExtendedPanID](#) attribute.

It is RECOMMENDED that fabrics only interact with instances of this cluster hosted on endpoints that declare a device type that explicitly allows this cluster; currently this includes the Network Infrastructure Manager and Thread Border Router device types. Networks from the ThreadNetworks list of any such directory instance, as well as the Active Dataset made available by any Thread Border Router via the [Thread Border Router Management Cluster](#), SHOULD be considered as potentially available networks.

In determining the user's preferred network, a directory instance on a Network Infrastructure Manager device SHOULD take precedence over other instances. Where a fabric has access to multiple Network Infrastructure Manager devices, it MAY give precedence to the directory instance on the Network Infrastructure Manager device considered to be acting as the primary Internet gateway device for the network.

Due to the sensitive nature of Thread network credentials, it is RECOMMENDED that fabrics obtain user consent before starting to contribute credentials to a particular directory instance. Contributions to a directory instance SHOULD be restricted to those Thread networks that are likely to be reachable from the infrastructure network to which the device hosting that directory is connected.