

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	PanDelta	int16	(-1 * (PanMax - PanMin)) to (PanMax - PanMin)		0	[MPAN].c+
1	TiltDelta	int16	(-1 * (TiltMax - TiltMin)) to (TiltMax - TiltMin)		0	[MTILT].c+
2	ZoomDelta	int8	(-1 * (ZoomMax - 1)) to (ZoomMax - 1)		0	[MZOOM].c+

11.3.7.2.1. PanDelta Field

This field SHALL indicate the change in the pan value in degrees relative to the current location. A value of 0 means no movement. A negative value means move left. A positive value means move right.

11.3.7.2.2. TiltDelta Field

This field SHALL indicate the change in the tilt value in degrees relative to the current location. A value of 0 means no movement. A negative value means move down. A positive value means move up.

11.3.7.2.3. ZoomDelta Field

This field SHALL indicate the percentage change in the zoom value relative to the current zoom value on the camera. A value of 0 means no change. A negative value means zoom out. A positive value means zoom in.

11.3.7.2.4. Effect on Receipt

The process below SHALL be followed by the camera when receiving this command:

- If the camera is already engaged in a command that results in a physical move, or if the camera is otherwise unable to apply the changes at this time:
 - Fail the command with the status code BUSY, and end processing with no other side effects.
- If PanDelta is present:
 - Add PanDelta to the Pan value in MptzPosition and clip the resulting value to be between PanMin and PanMax, inclusive.
- If TiltDelta is present:
 - Add TiltDelta to the Tilt value in MptzPosition and clip the resulting value to be between Tilt-