

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0	Zone	ZoneID	all	X			M
1	Sensitivity	uint8	1 to 10				PERZONE-SENS

11.7.6.10.1. Zone Field

This field SHALL be a [Motion ZoneID](#) found in the [Zone Management Cluster](#) which SHALL cause the trigger to activate. If not null, motion in this zone will activate the trigger. If null, motion anywhere in the complement of the union of all the [Zones](#) defined in the [Zone Management Cluster](#) on this endpoint will activate the trigger.

11.7.6.10.2. Sensitivity Field

This field SHALL indicate how sensitive the trigger for the specified Zone is, and SHALL match the same implementation specifics as the [Sensitivity](#) attribute in the [Zone Management Cluster](#). This field SHALL only be included when [PerZoneSensitivity](#) is supported, otherwise the value from [MotionSensitivity](#) is used.

11.7.6.11. TransportTriggerOptionsStruct Type

This struct encodes the conditions and options that configures the trigger for the push transport. The transport SHALL only start transmitting AV Streams when it's associated trigger is activated.

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0	Trigger-Type	TransportTriggerTypeEnum	all				M
1	Motion-Zones	list[TransportZoneOptionsStruct]		X			Trigger-Type == Motion
2	Motion-Sensitivity	uint8	1 to 10	X			Trigger-Type == Motion & !PERZONE-SENS
3	Motion-TimeControl	TransportMotionTriggerTimeControlStruct					Trigger-Type == Motion