

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
4	MaxPreRollLen	uint16	all				Trigger-Type == Command Trigger-Type == Motion

11.7.6.11.1. TriggerType Field

This field SHALL indicate the type of the transport trigger.

11.7.6.11.2. MotionZones Field

This field SHALL be a list of [TransportZoneOptionsStruct](#) containing the [Motion](#) Zones to trigger on. If this list is null, empty, or the [Zone Management Cluster](#) is not supported on this endpoint, then motion anywhere SHALL cause the trigger to activate. The maximum size of this list is [MaxZones](#).

11.7.6.11.3. MotionSensitivity Field

This field SHALL indicate how sensitive the trigger is to motion and SHALL match the same implementation specifics as [Sensitivity](#). This field SHALL NOT be used if the [PerZoneSensitivity](#) feature is supported, as a Zone specific value is available in the [TransportZoneOptionsStruct Sensitivity](#) field. If this is null and the [Zone Management Cluster](#) is supported on this endpoint, then the value found in the [Sensitivity](#) attribute in the [Zone Management Cluster](#) SHALL be used. If this is null and the [Zone Management Cluster](#) is not supported on this endpoint, a value of 10 SHALL be used.

11.7.6.11.4. MotionTimeControl Field

This field SHALL control timing around repeated activation of the trigger (see [TransportMotionTriggerTimeControlStruct](#)). If [TriggerType](#) is [Motion Value](#), this field SHALL be required.

11.7.6.11.5. MaxPreRollLen Field

This field SHALL indicate the maximum duration in milliseconds of pre-roll content that can be included, if the [TriggerType](#) is [Motion Value](#) or [Command Value](#), when the trigger activates.

A value of 0 SHALL indicate that no extra segments beyond the one containing the trigger point will be sent.

When using a non 0 value, the value SHALL be greater than or equal to the value of the stream's [KeyFrameInterval](#) and it SHOULD be a multiple of that value if larger.

The actual amount transmitted will always be less than or equal to the per stream storage amount found in the [MaxContentBufferSize](#).

Since a transmission caused by a trigger activation always begins on the Container Format's segment (or [key-frame](#)) boundary, if the trigger occurs mid segment, the entire segment still needs to be sent. This time delta between the actual trigger point and the start of the segment is counted as