

part of the pre-roll length. Thus, for more than the current segment to be sent as pre-roll, the full size of a segment must fit within the remainder of this length. For this reason, it is RECOMMENDED that a value of at least two times [SegmentDuration](#) be used so that a full segment is always included if available.

11.7.6.12. TransportMotionTriggerTimeControlStruct Type

This struct is used to encode a set of values for controlling the lifecycle of a motion triggered transport.

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0	InitialDuration	uint16	min 1				M
1	AugmentationDuration	uint16	all				M
2	MaxDuration	elapsed-s	min 1				M
3	BlindDuration	uint16	all				M

When a Motion Trigger is activated, either by receiving a [ManuallyTriggerTransport](#) command, or when motion is initially detected which matches a configured motion trigger, the Node SHALL start the push transport configured with this trigger see ([TransportOptionsStruct](#)).

This places the Node in a Motion Detected state, at which point the Node SHALL internally track two values.

TimeSinceActivation

The time in seconds since the trigger was activated.

MotionDetectedDuration

Initially set to the InitialDuration value.

However, if additional motion is detected during this period, the Node SHALL increase the MotionDetectedDuration value by the AugmentationDuration value. This process may occur repeatedly but after the first increase of MotionDetectedDuration the Node SHALL NOT increase the MotionDetectedDuration value unless the previous MotionDetectedDuration has been exceeded by the TimeSinceActivation.

If the TimeSinceActivation value exceeds the MaxDuration or MotionDetectedDuration value, the Node SHALL stop detecting motion for this trigger for the period of the BlindDuration value.

Since multiple triggers (and corresponding push transports) may be activated by the same motion, the Node SHALL perform this process independently for each motion trigger activated.