

### 5.6.3. Conditions

See the Base Device Type definition for conformance tags.

### 5.6.4. Cluster Requirements

Each endpoint supporting this device type SHALL include these clusters based on the conformance defined below.

| Cluster ID | Cluster Name                    | Client/Server | Quality | Conformance |
|------------|---------------------------------|---------------|---------|-------------|
| 0x0003     | Identify                        | Server        |         | M           |
| 0x0081     | Valve Configuration and Control | Server        |         | M           |
| 0x0404     | Flow Measurement                | Server        |         | O           |
| 0x0404     | Flow Measurement                | Client        |         | O           |

#### 5.6.4.1. Identify Cluster

This cluster is used to identify the device.

#### 5.6.4.2. Valve Configuration and Control Cluster

This cluster is used to configure and control (Open/Close) the valve.

#### 5.6.4.3. Flow Measurement Cluster

The cluster server, if present, SHALL be used to report the measured flow through the valve.

The cluster client, if present, MAY be used via binding to close a control loop of flow through the valve.

### 5.6.5. Device implementation recommendations

#### 5.6.5.1. Start Up Behavior

The start up behavior of a device with this device type, is currently not specified and is considered manufacturer specific. This means that the start up behavior and what is considered the "safe state", most suitable for the specific device, is defined by the manufacturer.

#### 5.6.5.2. Firmware Update

When a device with this device type needs to update its firmware (or restart for another reason), it is strongly recommended to only perform the update/restart when the valve is in its closed state, as well as ignoring any open request during this update/restart, given the chance a valve can unintentionally be left in the open state, for longer periods of time.