

12.1.5. Element Requirements

The table below lists qualities and conformance that override the cluster specification requirements. A blank table cell means there is no change to that item and the value from the cluster specification applies.

Cluster ID	Cluster Name	Element	Name	Constraint	Access	Conformance
0x0061	RVC Operational State	Event	OperationCompletion			M

12.1.6. Cluster Usage

This section describes how to control and monitor the operation of a Robotic Vacuum Cleaner device. This information is meant to clarify how the data dependencies within the device type's cluster composition are to be used.

Note that the device operations may also be the result of, or affected by, out-of-band actions such as robot physical button presses, internally scheduled events, vendor application requests, commands sent from other fabrics, internal device timeouts, etc. For example, a user may pause the robot during cleaning by using a Matter client and then resume cleaning by using a physical button of the device, or a robot may stop cleaning after an internal timeout occurs, and so forth.

The RVC Operational State cluster's `OperationalState` attribute SHALL be updated according to the state of the device, and therefore it SHOULD be used for monitoring purposes. Note that while the robot is in a cleaning cycle it may automatically seek the charger, recharge, and then resume cleaning.

The sections below describe various operational flows with preconditions and actions. The behavior in case the preconditions are not met is described in the corresponding cluster descriptions.

12.1.6.1. Starting Cleaning

12.1.6.1.1. Preconditions

If the `DirectModeChange` feature is not present, cleaning can only be started when the RVC Run Mode cluster's `CurrentMode` attribute is set to a mode that has the `Idle` mode tag associated with it, and the RVC Operational State cluster's `OperationalState` attribute is set to the `Stopped`, `Paused`, `Docked` or `Charging` state.

Note that if the RVC Clean Mode cluster is implemented, it determines the type of cleaning.

12.1.6.1.2. Actions

To attempt starting a cleaning operation, the RVC Run Mode cluster can be sent a `ChangeToMode` command with the `NewMode` field set to a mode that has the `Cleaning` mode tag associated with it.