

13.11.8.1. Starting the Oven

The oven operational attributes are set by sending the SetCookingParameters command of the Microwave Oven Control cluster with the values as intended by the user via a client. Oven operation can be started by sending the Start command via the Operational State cluster or one of its derivatives, if supported, or within the SetCookingParameters command via the StartAfterSetting attribute, if supported.

Upon setting the CookTime attribute via the SetCookingParameters command, the CountdownTime attribute of the Operational State cluster or one of its derivatives, if supported, is set to the same value as the CookTime attribute.

Once oven operation is started, the values previously sent by the SetCookingParameters command are used to control the oven operation and the CountdownTime attribute of the Operational State cluster or one of its derivatives begins counting down.

13.11.8.2. During Operation

While the oven is in the Running state, the CountdownTime attribute of the Operational State cluster or one of its derivatives counts down and the CookTime attribute of the Microwave Oven Control cluster remains fixed.

13.11.8.3. Stopping the Oven

Oven operation will end when either the Stop command of the Operational State cluster or one of its derivatives, if supported, is sent, the CountdownTime value reaches zero, or the oven is stopped via an out-of-band method.

It is recommended that when the oven enters the Stopped state of the Operational State cluster or one of its derived clusters, the attribute values of the Microwave Oven Control cluster be set to their default values by the server.

13.11.8.4. Adding More Time

When time is added to the CookTime attribute using the AddMoreTime command of the Microwave Oven Control cluster, the same amount of time is also added to the CountdownTime attribute of the Operational State cluster or one of its derivatives. See the CookTime attribute constraints and AddMoreTime command for more details.