

The Thread Interface associated with the Border Router SHALL be exposed via the Thread Border Router Management cluster.

The device MAY include a Network Commissioning cluster instance associated with the Wi-Fi or Ethernet adjacent infrastructure link interface on its Root Node. It SHOULD NOT include a Network Commissioning cluster instance associated with the Thread interface of the Border Router on its Root Node.

15.4.6.1. Thread Requirements

A device exposing the Thread Border Router device type SHALL be certified by the Thread Group as *Built on Thread: Border Router* based on Thread 1.4.0 or above.

The device SHALL implement a Thread Border Router as described by the Thread specification, and provide connectivity between the Thread network and the Wi-Fi / Ethernet hub network. The Thread Interface associated with the Border Router SHALL be exposed via the Thread Border Router Management cluster.

The Thread Border Router device SHALL support working as a Thread Parent for a minimum of 64 Thread Children simultaneously in any combination of Children End Device types. The Thread Border Router device SHALL support operating as a Thread Border Router in any Thread Network with up to 150 Thread nodes.

15.4.7. Cluster Usage

This section describes how to control and monitor the operation of a Thread Border Router.

The Thread Border Router Device Type provides the Thread Border Router Management Cluster with the goal of ensuring a seamless user experience when adding a new Border Router to form a new Thread network or join an existing one. This section presents informative configuration sequences that a Fabric Admin can set up to improve coverage and Internet access redundancy for Thread networks using the Thread Border Router device type. Four use cases are covered:

- Initial configuration of a Thread Border Router when no PAN exists
- Joining an existing PAN
- Sharing an existing PAN
- Moving to a new PAN

15.4.7.1. Initial configuration of Thread Border Router

In this use case, there is initially no PAN at the user's home. The user installs a Matter certified Thread Border Router to use Thread connectivity for their Matter devices.