

|                  |                             |
|------------------|-----------------------------|
| Example Response | {<br>"response_code":0<br>} |
|------------------|-----------------------------|

### 4.3. setLinkAudioQuality

For setting Link Audio Quality in each Zone.

#### **Request Parameters**

| name | type   | required | description                                                                                                   |
|------|--------|----------|---------------------------------------------------------------------------------------------------------------|
| zone | string | yes      | Specifies target zone. Available for zones with this function<br>Values: "main" / "zone2" / "zone3" / "zone4" |
| mode | string | yes      | Specifies Link Audio Quality setting<br>Values: Values gotten via /system/getFeatures                         |

|                 |                                                                                 |
|-----------------|---------------------------------------------------------------------------------|
| URI             | <BaseURL>[/secure]/v1/<zone>/setLinkAudioQuality?mode=<mode>                    |
| Method          | GET                                                                             |
| Example Request | http://{host}/YamahaExtendedControl/v1/main/setLinkAudioQuality?mode=compressed |

#### **Response Parameters**

| name          | type    | description                                                                                          |
|---------------|---------|------------------------------------------------------------------------------------------------------|
| response_code | integer | 0: Successful request / Others: Error<br>Refer to " <a href="#">Response Code List</a> " for details |

|                  |                             |
|------------------|-----------------------------|
| Example Response | {<br>"response_code":0<br>} |
|------------------|-----------------------------|