

## 5. Distribution (Link)

APIs in regard to Link distribution related setting and getting information

### 5.1. getDistributionInfo

For retrieving a Device information related to Link distribution

#### Request Parameters

|                 |                                                                 |
|-----------------|-----------------------------------------------------------------|
| URI             | <BaseURL>/v1/dist/getDistributionInfo                           |
| Method          | GET                                                             |
| Example Request | http://{host}/YamahaExtendedControl/v1/dist/getDistributionInfo |

#### Response Parameters

| name          | type         | Description                                                                                                                                                                                                       |
|---------------|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| response_code | integer      | 0: Successful request / Others: Error<br>Refer to " <a href="#">Response Code List</a> " for details                                                                                                              |
| group_id      | string       | Returns Group ID in 32-digit hex                                                                                                                                                                                  |
| group_name    | string       | Returns Group Name                                                                                                                                                                                                |
| role          | string       | Returns a role of Link distribution<br>Values: "server" / "client" / "none"                                                                                                                                       |
| status        | string       | Returns a construction state of distribution system<br>Valid only when role is Server. (Valid for API Version 2.00 or later)<br>Values: "building" / "working" / "deleting"                                       |
| server_zone   | string       | Returns target Zone ID that can work as a client of distributing server. If there's no parameter of this, "main" is implicitly chosen.<br>Values: "main" / "zone2" / "zone3" / "zone4"                            |
| client_list   | array        | Returns registered client IP address list<br>Valid only when the role is "server"                                                                                                                                 |
| - ip_address  | string       | Returns clients' IP Address                                                                                                                                                                                       |
| - data_type   | string       | Returns a type of distributed data<br>Values: "base" / "ext"                                                                                                                                                      |
| build_disable | array        | Returns information on whether distribution construction is prohibited or not<br>If there is no parameter, please handle as it is not in the construction prohibited state                                        |
| - role        | string       | Returns role of distribution that construction is prohibited<br>Values: "server" / "client"                                                                                                                       |
| - reasons     | string array | Returns informations of reason when construction of distribution is prohibited<br>Values: "unknown" / "not_implemented"                                                                                           |
| audio_dropout | boolean      | Returns whether sound interruption was detected during distribution<br>This value is cleared when CONNECT is executed or Network Module is reset<br>Even when distribution is canceled, this value is not cleared |