

- The [Acknowledged Message Counter](#) SHALL be included in the header.
- The [Protocol ID](#) SHALL be set to `PROTOCOL_ID_SECURE_CHANNEL`.
- The [Protocol Opcode](#) SHALL be set to [MRP Standalone Acknowledgement](#).

The rules for when to send this message are detailed in [Section 4.12.5.2.2, “Standalone acknowledgement processing”](#).

4.12.8. Parameters and Constants

This is a glossary of the MRP parameters used in this chapter with a brief description for each parameter. A Node SHALL use the provided default value for each parameter unless the message recipient Node advertises an alternate value for the parameter via Operational Discovery.

Table 22. Glossary of MRP parameters

Parameter Name	Description	Default Value
<i>MRP_MAX_TRANSMISSIONS</i>	The maximum number of transmission attempts for a given reliable message. The sender MAY choose this value as it sees fit.	5
<i>MRP_BACKOFF_BASE</i>	The base number for the exponential backoff equation.	1.6
<i>MRP_BACKOFF_JITTER</i>	The scaler for random jitter in the backoff equation.	0.25
<i>MRP_BACKOFF_MARGIN</i>	The scaler margin increase to backoff over the peer idle interval.	1.1
<i>MRP_BACKOFF_THRESHOLD</i>	The number of retransmissions before transitioning from linear to exponential backoff.	1
<i>MRP_STANDALONE_ACK_TIMEOUT</i>	Amount of time to wait for an opportunity to piggyback an acknowledgement on an outbound message before falling back to sending a standalone acknowledgement .	200 milliseconds

4.13. Unicast Communication

This section specifies the semantics of establishing a unicast session and the lifecycle of a unicast session.

Unicast sessions exist in one of two phases:

1. Session Establishment Phase: A series of well-defined unencrypted messages that aim to establish a shared key.
2. Application Data Phase: A series of ad-hoc encrypted messages exchanging interaction model protocol actions, application data, etc.