

Table 68. List of IdentificationDeclaration parameters

Parameter Name	Feature	Description
ErrorCode	All	Indicates errors incurred during commissioning.
NeedsPasscode	Coordinate PIN Dialogs	When NoPasscode field set to true, and the Commissioner determines that a Passcode code will be needed for commissioning.
NoAppsFound	Target Content Application	No apps with AccountLogin cluster implementation were found for the last IdentificationDeclaration request. Only apps which provide access to the vendor id of the Commissionee will be considered.
PasscodeDialogDisplayed	Coordinate PIN Dialogs	A Passcode input dialog is now displayed for the user on the Commissioner.
Commissioner- Passcode	Commissioner-Generated Passcode	A Passcode is now displayed for the user by the Commissioner.
QRCodeDisplayed	Commissioner-Generated Passcode	The user experience conveying a Passcode to the user also displays a QR code.
CancelPasscode	Coordinate Passcode Dialogs	Flag to indicate whether the Commissioner user has decided to exit the commissioning process.
Passcode- Length	Coordinate Passcode Dialogs	The length of the displayed passcode to inform the Commissionee of the number of digits to request from user.

The allowed values for the ErrorCode field are the following

Code	Description
0	No error
1	Commissionable Node discovery failed
2	PASE connection failed
3	PASE authentication failed (bad Passcode)
4	DAC validation failed
5	Already on fabric
6	Operational Node discovery failed
7	CASE connection failed
8	CASE authentication failed
9	Configuration failed
10	Binding Configuration failed