

- c. The **Custom Flow** element SHALL be set to 0 to indicate standard flow.
 - d. The **Discovery Capabilities Mask** SHALL have ONLY bit 2 set to indicate the Node is only discoverable on the IP network.
 - e. The **Passcode** element SHALL be set by the existing Administrator to the same value as the passcode chosen for this ECM operation.
 - f. The **Discriminator** element SHALL be set by the existing Administrator to the same value as the **Discriminator** parameter in [Section 11.19.8.1, “OpenCommissioningWindow”](#).
 - g. If multiple Nodes are subjected to ECM, the [Section 5.1.5, “TLV Content”](#) SHALL contain an entry with **kTag_NumberOfDevices** containing the number of devices that are expected to participate in the commissioning with this ECM operation.
 - h. When the Commissioning Timeout parameter of the OCW command is set to less than the allowed maximum (15 minutes), the [Section 5.1.5, “TLV Content”](#) SHALL contain an entry with **kTag_CommissioningTimeout** containing the value of the Commissioning Timeout parameter used for this ECM operation.
3. If only audio output is supported, the temporary Onboarding Payload SHALL be delivered using a voice prompt of the Manual Pairing Code format. A method SHOULD be available for the user to have the pairing code repeated.

Remote UIs, both visual and audio — such as a manufacturer-specific mobile app or a web UI — are expressly permitted in the set of acceptable mechanisms for conveyance of the onboarding material.

This method allows a current Administrator to set multiple Nodes for commissioning with a new administrator with an appropriate **Commissioning Window**, by opening a commissioning window using the [OpenCommissioningWindow](#) command and sending the **PAKE** passcode verifier to a series of Nodes. The new Administrator uses the information in [Manual Pairing Code](#) to discover the Nodes that are in Commissioning mode and commission them using the new passcode.

The following steps describe a possible sequence of events for ECM commissioning:

1. Current Administrator puts the Node(s) in commissioning mode for a specified time window with a new setup passcode, and receives success responses from the involved Node(s) on the [OpenCommissioningWindow](#) command.
 - a. When one or more **ICD** are among the targeted Nodes, the current Administrator can guide the user to perform some action to 'wake' these devices from their sleep cycle.
2. Current Administrator presents Onboarding Payload as described [above](#).
3. New Administrator completes commissioning within the prescribed window using steps outlined in [Figure 45, “Commissioning flow diagram”](#).

5.6.4. Open Commissioning Window

The following sequence diagram shows steps current Administrator takes to enable [OpenCommissioningWindow](#).