

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0	AttributeID	attrib-id					M
1	Status-Code	status					M

7.15.5.1. AttributeID Field

This field SHALL indicate the ID of the attribute with the associated [StatusCode](#).

7.15.5.2. StatusCode Field

This field SHALL indicate the atomic status of an attribute.

7.15.6. AtomicRequest Command

This command is used to begin, commit or cancel an atomic write.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Request-Type	AtomicRequestTypeEnum				M
1	AttributeRequests	list[attrib-id]				M
2	Timeout	uint16				desc

7.15.6.1. RequestType Field

This field SHALL indicate the type of atomic request being made by the client.

7.15.6.2. AttributeRequests Field

This field SHALL indicate a list of attribute IDs the client wishes to write to during an atomic request.

7.15.6.3. Timeout Field

This field SHALL indicate an interval in milliseconds in which the client will either commit or roll-back the atomic write. If the value of the RequestType field is BeginWrite, this field SHALL be included, otherwise it SHALL be omitted.

7.15.6.4. Effect on Receipt

If an AtomicRequest command is received without an accessing fabric, the server SHALL return a status code of INVALID_COMMAND.