

- The Path field SHALL indicate a concrete path.

8.9.5.3. AttributeStatusIB

This is used to indicate an invalid attribute data request path, or an error accessing the data, or success writing to an attribute path.

Info Field	Type	Quality	Conformance
Path	AttributePathIB		M
Status	StatusIB		M

- The Path field SHALL indicate a concrete path.

8.9.5.4. StatusIB

This is used to respond with errors or success to actions. A success Status field is valid for every layer. A non-success Status field is either defined in this layer, or generated and recognized by another layer. ClusterStatus is defined in a cluster specification.

See [Section 8.10, “Status Codes”](#) for valid values for Status.

Info Field	Type	Quality	Conformance
Status	status		M
ClusterStatus	status		O

Status Field

This is the one of the common status code values defined in [Status Code Table](#).

ClusterStatus Field

ClusterStatus values are defined in a cluster specification.

8.10. Status Codes

The table below lists global status codes for the Interaction Model. These MAY be used by interaction model processing of actions and as common status codes for cluster specifications. All values not defined here SHALL be reserved (per general conventions). Cluster specifications that wish to communicate a status not defined in this table MAY use a cluster-specific status code as described in [Status Codes](#).

8.10.1. Status Code Table

Status Code	Value	Summary
0x00	SUCCESS	Operation was successful.
0x01	FAILURE	Operation was not successful.