

Value	Name	Summary	Conformance
1	OverTemp	The Node detects the temperature of this battery power source is above ideal operating conditions.	M
2	UnderTemp	The Node detects the temperature of this battery power source is below ideal operating conditions.	M

11.7.6.3. BatChargeFaultEnum Type

This data type is derived from enum8.

Value	Name	Summary	Conformance
0	Unspecified	The Node detects an unspecified fault on this battery source.	M
1	AmbientTooHot	The Node detects the ambient temperature is above the nominal range for this battery source.	M
2	AmbientTooCold	The Node detects the ambient temperature is below the nominal range for this battery source.	M
3	BatteryTooHot	The Node detects the temperature of this battery source is above the nominal range.	M
4	BatteryTooCold	The Node detects the temperature of this battery source is below the nominal range.	M
5	BatteryAbsent	The Node detects this battery source is not present.	M
6	BatteryOverVoltage	The Node detects this battery source is over voltage.	M