

deemed to have occurred, including, for example, obtaining IP addresses, or the execution of necessary internal retries.

11.9.6.5. InterfaceEnabled Attribute

This attribute SHALL indicate whether the associated network interface is enabled or not. By default all network interfaces SHOULD be enabled during initial commissioning (InterfaceEnabled set to true).

It is undefined what happens if InterfaceEnabled is written to false on the same interface as that which is used to write the value. In that case, it is possible that the Administrator would have to await expiry of the fail-safe, and associated recovery of network configuration to prior safe values, before being able to communicate with the node again (see [Section 11.10.7.2, “ArmFailSafe”](#)).

It MAY be possible to disable Ethernet interfaces but it is implementation-defined. If not supported, a write to this attribute with a value of false SHALL fail with a status of INVALID_ACTION. When disabled, an Ethernet interface would no longer employ media detection. That is, a simple unplug and replug of the cable SHALL NOT re-enable the interface.

On Ethernet-only Nodes, there SHALL always be at least one of the Network Commissioning server cluster instances with InterfaceEnabled set to true.

11.9.6.6. LastNetworkingStatus Attribute

This attribute SHALL indicate the status of the last attempt either scan or connect to an operational network, using this interface, whether by invocation of the [ConnectNetwork](#) command or by autonomous connection after loss of connectivity or during initial establishment. If no such attempt was made, or no network configurations exist in the [Networks](#) attribute, then this attribute SHALL be set to null.

This attribute is present to assist with error recovery during Network commissioning and to assist in non-concurrent networking commissioning flows.

11.9.6.7. LastNetworkID Attribute

This attribute SHALL indicate the NetworkID used in the last attempt to connect to an operational network, using this interface, whether by invocation of the [ConnectNetwork](#) command or by autonomous connection after loss of connectivity or during initial establishment. If no such attempt was made, or no network configurations exist in the [Networks](#) attribute, then this attribute SHALL be set to null.

If a network configuration is removed from the [Networks](#) attribute using the RemoveNetwork command after a connection attempt, this field MAY indicate a NetworkID that is no longer configured on the Node.

This attribute is present to assist with error recovery during Network commissioning and to assist in non-concurrent networking commissioning flows.