

11.9.6.8. LastConnectErrorValue Attribute

This attribute SHALL indicate the ErrorValue used in the last failed attempt to connect to an operational network, using this interface, whether by invocation of the [ConnectNetwork](#) command or by autonomous connection after loss of connectivity or during initial establishment. If no such attempt was made, or no network configurations exist in the [Networks](#) attribute, then this attribute SHALL be set to null.

If the last connection succeeded, as indicated by a value of Success in the [LastNetworkingStatus](#) attribute, then this field SHALL be set to null.

This attribute is present to assist with error recovery during Network commissioning and to assist in non-concurrent networking commissioning flows.

11.9.6.9. SupportedWiFiBands Attribute

This attribute SHALL indicate all the frequency bands supported by the Wi-Fi interface configured by the cluster instance.

11.9.6.10. SupportedThreadFeatures Attribute

This attribute SHALL indicate all of the Thread features supported by the Thread interface configured by the cluster instance.

This attribute is primarily used to determine the most important general capabilities of the Thread interface associated with the cluster instance, as opposed to the current runtime dynamic configuration. Note that most run-time details of the actual Thread interface are found in the [Thread Network Diagnostics cluster](#), if supported.

11.9.6.11. ThreadVersion Attribute

This attribute SHALL indicate the Thread version supported by the Thread interface configured by the cluster instance.

The format SHALL match the value mapping found in the "Version TLV" section of [Thread specification](#). For example, Thread 1.3.0 would have [ThreadVersion](#) set to 4.

11.9.7. Commands

ID	Name	Direction	Response	Access	Conformance
0x00	ScanNetworks	client ⇒ server	ScanNetworksResponse	A	WI TH
0x01	ScanNetworksResponse	client ⇐ server	N		WI TH
0x02	AddOrUpdateWiFiNetwork	client ⇒ server	NetworkConfigResponse	A	WI