

ErrorValue Field

- ErrorValue interpretation for Wi-Fi association errors:
 - On any association failure during enabling of a network, the ErrorValue field SHALL be set to the Status Code value that was present in the last frame related to association where Status Code was not equal to zero and which caused the failure of a final retry attempt, if this final failure was due to one of the following Management frames:
 - Association Response (Type 0, Subtype 1)
 - Reassociation Response (Type 0, Subtype 3)
 - Authentication (Type 0, Subtype 11)
 - Table 9-50 "Status Codes" in [IEEE 802.11-2020](#) contains a description of all values possible, which can unambiguously be used to determine the cause, such as an invalid security type, unsupported rate, etc.
- Otherwise, the ErrorValue field SHALL contain an implementation-dependent value which MAY be used by a reader of the structure to record, report or diagnose the failure.

11.9.7.10. ReorderNetwork Command

This command is used to re-order the network configuration list.

This command SHALL set the specific order of the network configuration selected by its NetworkID in the [Networks](#) attribute to match the position given by NetworkIndex.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	NetworkID	octstr	1 to 32			M
1	NetworkIndex	uint8	desc			M
2	Breadcrumb	uint64	all			O

NetworkID Field

This field SHALL contain the NetworkID for the entry to reorder: the SSID for Wi-Fi and XPAN ID for Thread.

NetworkIndex Field

This field SHALL contain the 0-based index of the new desired position of the entry in the [Networks](#) attribute.

Breadcrumb Field

See [Section 11.9.7.1.2, “Breadcrumb Field”](#) for usage.