

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0008	TestEventTriggersEnabled	bool	all			R V	M
0x0009	DoNotUse						X

Attribute 0x0009 SHALL NOT be used in any implementation of previous, current or future version of this specification.

11.12.6.1. NetworkInterfaces Attribute

The NetworkInterfaces attribute SHALL be a list of [NetworkInterface](#) structs. Each logical network interface on the Node SHALL be represented by a single entry within the NetworkInterfaces attribute.

11.12.6.2. RebootCount Attribute

The RebootCount attribute SHALL indicate a best-effort count of the number of times the Node has rebooted. The RebootCount attribute SHOULD be incremented each time the Node reboots. The RebootCount attribute SHALL NOT be incremented when a Node wakes from a low-power or sleep state. The RebootCount attribute SHALL only be reset to 0 upon a factory reset of the Node.

11.12.6.3. UpTime Attribute

The UpTime attribute SHALL indicate a best-effort assessment of the length of time, in seconds, since the Node's last reboot. This attribute SHOULD be incremented to account for the periods of time that a Node is in a low-power or sleep state. This attribute SHALL only be reset upon a device reboot. This attribute SHALL be based on the same System Time source as those used to fulfill any usage of the [systemtime-us](#) and [systemtime-ms](#) data types within the server.

11.12.6.4. TotalOperationalHours Attribute

The TotalOperationalHours attribute SHALL indicate a best-effort attempt at tracking the length of time, in hours, that the Node has been operational. The TotalOperationalHours attribute SHOULD be incremented to account for the periods of time that a Node is in a low-power or sleep state. The TotalOperationalHours attribute SHALL only be reset upon a factory reset of the Node.

11.12.6.5. BootReason Attribute

The BootReason attribute SHALL indicate the reason for the Node's most recent boot.

11.12.6.6. ActiveHardwareFaults Attribute

The ActiveHardwareFaults attribute SHALL indicate the set of faults currently detected by the Node. When the Node detects a fault has been raised, the appropriate [HardwareFaultEnum](#) value SHALL be added to this list. This list SHALL NOT contain more than one instance of a specific [HardwareFaultEnum](#) value. When the Node detects that all conditions contributing to a fault has been