

cleared, the corresponding [HardwareFaultEnum](#) value SHALL be removed from this list. An empty list SHALL indicate there are currently no active faults. The order of this list SHOULD have no significance. Clients interested in monitoring changes in active faults MAY subscribe to this attribute, or they MAY subscribe to [HardwareFaultChange](#).

11.12.6.7. ActiveRadioFaults Attribute

The ActiveRadioFaults attribute SHALL indicate the set of faults currently detected by the Node. When the Node detects a fault has been raised, the appropriate [RadioFaultEnum](#) value SHALL be added to this list. This list SHALL NOT contain more than one instance of a specific [RadioFaultEnum](#) value. When the Node detects that all conditions contributing to a fault has been cleared, the corresponding [RadioFaultEnum](#) value SHALL be removed from this list. An empty list SHALL indicate there are currently no active faults. The order of this list SHOULD have no significance. Clients interested in monitoring changes in active faults MAY subscribe to this attribute, or they MAY subscribe to [RadioFaultChange](#).

11.12.6.8. ActiveNetworkFaults Attribute

The ActiveNetworkFaults attribute SHALL indicate the set of faults currently detected by the Node. When the Node detects a fault has been raised, the appropriate [NetworkFaultEnum](#) value SHALL be added to this list. This list SHALL NOT contain more than one instance of a specific [NetworkFaultEnum](#) value. When the Node detects that all conditions contributing to a fault has been cleared, the corresponding [NetworkFaultEnum](#) value SHALL be removed from this list. An empty list SHALL indicate there are currently no active faults. The order of this list SHOULD have no significance. Clients interested in monitoring changes in active faults MAY subscribe to this attribute, or they MAY subscribe to [NetworkFaultChange](#).

11.12.6.9. TestEventTriggersEnabled Attribute

The TestEventTriggersEnabled attribute SHALL indicate whether the Node has any [TestEventTrigger](#) configured. When this attribute is true, the Node has been configured with one or more test event triggers by virtue of the internally programmed EnableKey value (see [Section 11.12.7.1, “TestEventTrigger Command”](#)) being set to a non-zero value. This attribute can be used by Administrators to detect if a device was inadvertently commissioned with test event trigger mode enabled, and take appropriate action (e.g. warn the user and/or offer to remove all fabrics on the Node).

11.12.7. Commands

ID	Name	Direction	Response	Access	Conformance
0x00	TestEventTrigger	client ⇒ server	Y	M	M
0x01	TimeSnapshot	client ⇒ server	TimeSnapshotResponse	O	M
0x02	TimeSnapshotResponse	client ⇐ server	N		M
0x03	Payload-TestRequest	client ⇒ server	PayloadTestResponse	M	DMTEST