

Bit	Code	Feature	Summary
0	PKTCNT	PacketCounts	Server supports the counts for the number of received and transmitted packets on the Thread interface.
1	ERRCNT	ErrorCounts	Server supports the counts for the number of errors that have occurred during the reception and transmission of packets on the Thread interface.
2	MLECNT	MLECounts	Server supports the counts for various MLE layer happenings.
3	MACCNT	MACCounts	Server supports the counts for various MAC layer happenings.

11.14.5. Data Types

11.14.5.1. NetworkFaultEnum Type

This data type is derived from [enum8](#).

Value	Name	Summary	Conformance
0	Unspecified	Indicates an unspecified fault.	M
1	LinkDown	Indicates the Thread link is down.	M
2	HardwareFailure	Indicates there has been Thread hardware failure.	M
3	NetworkJammed	Indicates the Thread network is jammed.	M

11.14.5.2. ConnectionStatusEnum Type

This data type is derived from [enum8](#).

Value	Name	Summary	Conformance
0	Connected	Node is connected	M
1	NotConnected	Node is not connected	M