

attribute SHALL be reset to 0 upon a reboot of the Node.

11.14.6.8. NeighborTable Attribute

This attribute SHALL indicate the current list of Nodes that comprise the neighbor table on the Node.

11.14.6.9. RouteTable Attribute

This attribute SHALL indicate the current list of router capable Nodes for which routes have been established.

11.14.6.10. PartitionId Attribute

This attribute SHALL indicate the Thread Leader Partition Id for the Thread network to which the Node is joined. This attribute SHALL be null if not attached to a Thread network.

11.14.6.11. Weighting Attribute

This attribute SHALL indicate the Thread Leader Weight used when operating in the Leader role. This attribute SHALL be null if not attached to a Thread network.

11.14.6.12. DataVersion Attribute

This attribute SHALL indicate the full Network Data Version the Node currently uses. This attribute SHALL be null if not attached to a Thread network.

11.14.6.13. StableDataVersion Attribute

This attribute SHALL indicate the Network Data Version for the stable subset of data the Node currently uses. This attribute SHALL be null if not attached to a Thread network.

11.14.6.14. LeaderRouterId Attribute

This attribute SHALL indicate the 8-bit LeaderRouterId the Node SHALL attempt to utilize upon becoming a router or leader on the Thread network. This attribute SHALL be null if not attached to a Thread network.

11.14.6.15. DetachedRoleCount Attribute

This attribute SHALL indicate the number of times the Node entered the OT_DEVICE_ROLE_DETACHED role as specified within the Thread specification. This value SHALL only be reset upon a Node reboot.

11.14.6.16. ChildRoleCount Attribute

This attribute SHALL indicate the number of times the Node entered the OT_DEVICE_ROLE_CHILD role as specified within the Thread specification. This value SHALL only be reset upon a Node reboot.