

11.14.7. Commands

ID	Name	Direction	Response	Access	Conformance
0x00	ResetCounts	client ⇒ server	Y	M	ERRCNT

11.14.7.1. ResetCounts Command

This command is used to reset the count attributes.

Reception of this command SHALL reset the following attributes to 0:

- [OverrunCount](#)

Upon completion, this command SHALL send a status code of SUCCESS back to the initiator.

11.14.8. Events

ID	Name	Priority	Access	Conformance
0x00	ConnectionStatus	INFO	V	O
0x01	NetworkFault-Change	INFO	V	O

11.14.8.1. NetworkFaultChange Event

The NetworkFaultChange Event SHALL indicate a change in the set of network faults currently detected by the Node.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Current	list[Network-FaultEnum]	max 4			M
1	Previous	list[Network-FaultEnum]	max 4			M

Current Field

This field SHALL represent the set of faults currently detected, as per [Section 11.14.5.1, “Network-FaultEnum Type”](#).

Previous Field

This field SHALL represent the set of faults detected prior to this change event, as per [Section 11.14.5.1, “NetworkFaultEnum Type”](#).

11.14.8.2. ConnectionStatus Event

The ConnectionStatus Event SHALL indicate that a Node’s connection status to a Thread network has changed.