

11.15.6.9. PacketMulticastTxCount Attribute

This attribute SHALL indicate the number of multicast packets transmitted by the Node.

11.15.6.10. PacketUnicastRxCount Attribute

This attribute SHALL indicate the number of unicast packets received by the Node.

11.15.6.11. PacketUnicastTxCount Attribute

This attribute SHALL indicate the number of unicast packets transmitted by the Node.

11.15.6.12. CurrentMaxRate Attribute

This attribute SHALL indicate the current maximum PHY rate of transfer of data in bits-per-second.

11.15.6.13. OverrunCount Attribute

This attribute SHALL indicate the number of packets dropped either at ingress or egress, due to lack of buffer memory to retain all packets on the network interface. The attribute SHALL be reset to 0 upon a reboot of the Node.

11.15.7. Commands

ID	Name	Direction	Response	Access	Conformance
0x00	ResetCounts	client ⇒ server	Y	O	ERRCNT

11.15.7.1. ResetCounts Command

This command is used to reset the count attributes.

Reception of this command SHALL reset the following attributes to 0:

- [BeaconLostCount](#)
- [BeaconRxCount](#)
- [PacketMulticastRxCount](#)
- [PacketMulticastTxCount](#)
- [PacketUnicastRxCount](#)
- [PacketUnicastTxCount](#)

11.15.8. Events

ID	Name	Priority	Quality	Access	Conformance
0x00	Disconnection	info		V	O
0x01	Association-Failure	info		V	O