

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	DSTOffsetRequired	bool	all		true	M

DSTOffsetRequired Field

If the node supports a time zone database with information for the time zone that will be applied, it MAY use this information to set the [DSTOffset](#) attribute. If the node is setting its own DSTOffset attribute, the DSTOffsetRequired field SHALL be set to false, otherwise it SHALL be set to true.

11.17.9.5. SetDSTOffset Command

This command is used to set the DST offsets for a node.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	DSTOffset	list[DSTOffsetStruct]				M

- If the length of DSTOffset is larger than DSTOffsetListMaxSize, the node SHALL respond with RESOURCE_EXHAUSTED.
- Else if the list entries do not conform to the list requirements for [DSTOffset](#) attribute, the node SHALL respond with CONSTRAINT_ERROR.

If there are no errors in the list, the DSTOffset field SHALL be copied to the DSTOffset attribute.

If the DSTOffset attribute change causes a corresponding change to the DST state, a [DSTStatus](#) event SHALL be generated. If the list is empty, the node SHALL generate a [DSTTableEmpty](#) event.

11.17.9.6. SetDefaultNTP Command

This command is used to set the DefaultNTP attribute.

If the DefaultNTP Address field does not conform to the requirements in the [DefaultNTP](#) attribute description, the command SHALL fail with a status code of INVALID_COMMAND. If the node does not support DNS resolution (as specified in [SupportsDNSResolve](#)) and the provided Address is a domain name, the command SHALL fail with a status code of INVALID_COMMAND. Otherwise, the node SHALL set the DefaultNTP attribute to match the DefaultNTP provided in this command.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	DefaultNTP	string	max 128	X		M

DefaultNTP Field

This field contains the address of an NTP server than can be used as a fallback for time synchronization. The format of this field SHALL follow the requirements in the [DefaultNTP](#) attribute