

These certificates are installed through the [AddTrustedRootCertificate](#) command.

Depending on the method of storage employed by the server, either shared storage for identical root certificates shared by many fabrics, or individually stored root certificate per fabric, multiple identical root certificates MAY legally appear within the list.

To match a root with a given fabric, the root certificate's subject and subject public key need to be cross-referenced with the NOC or ICAC certificates that appear in the [NOCs](#) attribute for a given fabric.

Upon Factory Data Reset, this attribute SHALL be set to a default value whereby the list is empty.

11.18.5.6. CurrentFabricIndex Attribute

This attribute SHALL indicate the [accessing fabric index](#).

This attribute is useful to contextualize [Fabric-Scoped](#) entries obtained from response commands or attribute reads, since a given Fabric may be referenced by a different Fabric Index locally on a remote Node.

11.18.6. Commands

ID	Name	Direction	Response	Access	Conformance
0x00	AttestationRequest	client ⇒ server	AttestationResponse	A	M
0x01	AttestationResponse	client ⇐ server	N		M
0x02	Certificate-ChainRequest	client ⇒ server	Certificate-ChainResponse	A	M
0x03	Certificate-ChainResponse	client ⇐ server	N		M
0x04	CSRRequest	client ⇒ server	CSRResponse	A	M
0x05	CSRResponse	client ⇐ server	N		M
0x06	AddNOC	client ⇒ server	NOCResponse	A	M
0x07	UpdateNOC	client ⇒ server	NOCResponse	A F	M
0x08	NOCResponse	client ⇐ server	N		M
0x09	UpdateFabricLabel	client ⇒ server	NOCResponse	A F	M
0x0A	RemoveFabric	client ⇒ server	NOCResponse	A	M
0x0B	AddTrusted-RootCertificate	client ⇒ server	Y	A	M