

ID	Name	Type	Constraint	Quality	Fallback	Conformance
1	AttestationSignature	octstr	64			M

AttestationElements Field

This field SHALL contain the octet string of the serialized attestation_elements_message.

AttestationSignature Field

This field SHALL contain the octet string of the necessary attestation_signature as described in [Section 11.18.4.7, “Attestation Information”](#).

11.18.6.3. CertificateChainRequest Command

This command is used to request a certificate from the device attestation certificate chain.

If the CertificateType is not a valid value per [CertificateChainTypeEnum](#) then the command SHALL fail with a Status Code of INVALID_COMMAND.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	CertificateType	CertificateChainTypeEnum	desc			M

11.18.6.4. CertificateChainResponse Command

This command is used to report the results of the CertificateChainRequest command. This command SHALL be generated in response to a [CertificateChainRequest command](#).

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Certificate	octstr	max 600			M

Certificate Field

This field SHALL be the DER encoded certificate corresponding to the CertificateType field in the [CertificateChainRequest command](#).

11.18.6.5. CSRRequest Command

This command is used to perform a CSR request.

This command SHALL be generated to execute the [Node Operational CSR Procedure](#) and subsequently return the [NOCSR Information](#), in the form of a [CSRResponse Command](#).