

value range checks for identifiers such as Fabric ID and Node ID. If this validation fails, the error status SHALL be `InvalidNodeOpId` if the `matter-node-id` attribute in the subject DN of the NOC has a value outside the Operational Node ID range and `InvalidNOC` for all other failures.

If any of the above validation checks fail, the server SHALL immediately respond to the client with an `NOCResponse`. The `StatusCode` field of the `NOCResponse` SHALL be set to the error status value specified in the above validation checks.

These certificate validation steps are performed to ensure that operational credentials installed match an operational key pair generated by the Device and respect the trust model assumptions expressed in [Section 6.4.5.1, “Node Operational Certificate \(NOC\)”](#).

Handling Errors

For any error described in the following subsections, the device SHALL immediately respond to the client with an `NOCResponse` with the prescribed `StatusCode` field, and SHALL leave all non-volatile state of the device untouched, as if the `AddNOC` command had never been received. The information about the last CSR state associated with this session SHALL also be untouched in this case, so that a valid `AddNOC` command MAY still be issued later that would match that CSR state. The `DebugText` field in the `NOCResponse` MAY be filled with debug information.

The following failed preconditions error cases apply to all invocations of `AddNOC`:

- If the device already has the `CommissionedFabrics` attribute equal to the `SupportedFabrics` attribute, then the device’s operational credentials table is considered full and the device SHALL process the error by responding with a `StatusCode` of `TableFull` as described in [Section 11.18.6.7.2, “Handling Errors”](#).
- If no context or memory exists of a prior `CSRRequest` command having been invoked in the **same secure session** as that which is receiving this `AddNOC` or `UpdateNOC` invocation, then the Node SHALL process the error by responding with a `StatusCode` of `MissingCsr` as described in [Section 11.18.6.7.2, “Handling Errors”](#).

11.18.6.8. AddNOC Command

This command is used to add a new NOC to the device.

This command SHALL add a new `NOC` chain to the device and commission a new Fabric association upon successful validation of all arguments and preconditions.

The new value SHALL immediately be reflected in the `NOCs` list attribute.

A Commissioner or Administrator SHALL issue this command after issuing the `CSRRequest command` and receiving its response.

A Commissioner or Administrator SHOULD issue this command after performing the [Attestation Procedure](#).