

8. The incoming IPKValue SHALL be stored in the Fabric-scoped slot within the Group Key Management cluster (see [Section 11.2.7.1, “KeySetWrite Command”](#)), for subsequent use during [CASE](#).
9. The Fabric Index associated with the armed fail-safe context (see [Section 11.10.7.2, “ArmFail-Safe”](#)) SHALL be updated to match the Fabric Index just allocated.
10. If the current secure session was established with [PASE](#), the receiver SHALL:
 - a. Augment the [secure session context](#) with the FabricIndex generated above, such that subsequent interactions have the proper [accessing fabric](#).
11. If the current secure session was established with [CASE](#), subsequent configuration of the newly installed Fabric requires the opening of a new CASE session from the Administrator from the Fabric just installed. This Administrator is the one listed in the [CaseAdminSubject](#) argument.

Thereafter, the Node SHALL respond with an NOCResponse with a [StatusCode](#) of OK and a FabricIndex field matching the FabricIndex under which the new [Node Operational Certificate \(NOC\)](#) is scoped.

11.18.6.9. UpdateNOC Command

This command is used to update an existing NOC on the device.

This command SHALL replace the NOC and optional associated ICAC (if present) scoped under the accessing fabric upon successful validation of all arguments and preconditions. The new value SHALL immediately be reflected in the [NOCs](#) list attribute.

A Commissioner or Administrator SHALL issue this command after issuing the [CSRRequest Command](#) and receiving its response.

A Commissioner or Administrator SHOULD issue this command after performing the [Attestation Procedure](#).

Access Modifier: Fabric Scoped						
ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	NOCValue	octstr	max 400			M
1	ICACValue	octstr	max 400			O

Effect on Receipt

If this command is received without an armed fail-safe context (see [Section 11.10.7.2, “ArmFail-Safe”](#)), then this command SHALL fail with a FAILSAFE_REQUIRED status code sent back to the initiator.

If a prior UpdateNOC or AddNOC command was successfully executed within the fail-safe timer period, then this command SHALL fail with a CONSTRAINT_ERROR status code sent back to the initiator.

If a prior [AddTrustedRootCertificate](#) command was successfully invoked within the fail-safe timer