

- `noc_private_key` is the operational private key associated with the [Node Operational Key Pair](#) for the FabricIndex requested in the associated [SignVIDVerificationRequest](#).
- `vendor_id_verification_tbs` := `fabric_binding_version || client_challenge || attestation_challenge || fabric_index || vendor_fabric_binding_message || <vid_verification_statement>`
 - `fabric_binding_version` is the value from the FabricBindingVersion field of this [SignVIDVerificationResponse](#).
 - `client_challenge` is the 32-octet [ClientChallenge](#) from the [SignVIDVerificationRequest](#).
 - `attestation_challenge` is the AttestationChallenge from a [CASE session](#), [resumed CASE session](#), or [PASE session](#) depending on the method used to establish the current secure session context over which the response will be sent.
 - `fabric_index` is the 1-octet value of [FabricIndex](#) from the [SignVIDVerificationRequest](#).
 - `vendor_fabric_binding_message` is the octet string of the vendor_fabric_binding_message defined in [Section 6.4.10.1, “Algorithm”](#).
 - `vid_verification_statement` is the 85-octet (for cryptographic primitives mapping 1.0) value from the [VIDVerificationStatement](#) field of the entry in the [Fabrics](#) attribute associated with the `fabric_index`, if present. If there is no such field in the [Fabrics](#) attribute for the fabric_index specified, this field SHALL be omitted from the `vendor_id_verification_tbs` message.

11.19. Administrator Commissioning Cluster

This cluster is used to trigger a Node to allow a new Administrator to commission it. It defines Attributes, Commands and Responses needed for this purpose.

There are two methods of commissioning, Basic Commissioning which MAY be supported and is described in [Section 5.6.2, “Basic Commissioning Method \(BCM\)”](#) and Enhanced Commissioning which SHALL be supported and is described in [Section 5.6.3, “Enhanced Commissioning Method \(ECM\)”](#).

For the management of Operational Credentials and Trusted Root Certificates, the [Operational Credentials cluster](#) is used.

If the Administrator Commissioning Cluster server instance is present on an endpoint with the Root Node device type in the Descriptor cluster DeviceTypeList, then:

- The Commissioning Window SHALL be opened or closed on the node that the Root Node endpoint is on.
- The attributes SHALL indicate the state of the node that the Root Node endpoint is on.

If the Administrator Commissioning Cluster server instance is present on an endpoint with the Bridged Node device type in the Descriptor cluster DeviceTypeList, then:

- The Commissioning Window SHALL be opened or closed on the node represented by the Bridged Node.
- The attributes SHALL indicate the state of the node that is represented by the Bridged Node.