

11.19.7.2. AdminFabricIndex Attribute

When the [WindowStatus](#) attribute is not set to WindowNotOpen, this attribute SHALL indicate the FabricIndex associated with the Fabric scoping of the Administrator that opened the window. This MAY be used to cross-reference in the [Fabrics](#) attribute of the [Operational Credentials](#) cluster.

If, during an open commissioning window, the fabric for the Administrator that opened the window is removed, then this attribute SHALL be set to null.

When the [WindowStatus](#) attribute is set to WindowNotOpen, this attribute SHALL be set to null.

11.19.7.3. AdminVendorId Attribute

When the [WindowStatus](#) attribute is not set to WindowNotOpen, this attribute SHALL indicate the [Vendor ID](#) associated with the Fabric scoping of the Administrator that opened the window. This field SHALL match the [VendorID](#) field of the [Fabrics](#) attribute list entry associated with the Administrator having opened the window, at the time of window opening. If the fabric for the Administrator that opened the window is removed from the node while the commissioning window is still open, this attribute SHALL NOT be updated.

When the [WindowStatus](#) attribute is set to WindowNotOpen, this attribute SHALL be set to null.

11.19.8. Commands

ID	Name	Direction	Response	Access	Conformance
0x00	OpenCommissioningWindow	client ⇒ server	Y	A T	M
0x01	OpenBasicCommissioningWindow	client ⇒ server	Y	A T	BC
0x02	RevokeCommissioning	client ⇒ server	Y	A T	M

Only one commissioning window can be active at a time. If a Node receives another open commissioning command when an Open Commissioning Window is already active, it SHALL return a failure response (see [Section 11.19.6](#), “[Status Codes](#)”).

11.19.8.1. OpenCommissioningWindow Command

This command is used by a current Administrator to instruct a Node to go into commissioning mode. The [Enhanced Commissioning Method](#) specifies a window of time during which an already commissioned Node accepts [PASE](#) sessions. The current Administrator SHALL specify a timeout value for the duration of the OpenCommissioningWindow command.

When the OpenCommissioningWindow command expires or commissioning completes, the Node SHALL remove the Passcode by deleting the [PAKE](#) passcode verifier as well as stop publishing the DNS-SD record corresponding to this command as described in [Section 4.3.1](#), “[Commissionable](#)”.