

approved request.

The server SHALL return FAILURE if the CommissionNode command is not sent from the same NodeID and on the same fabric as the RequestCommissioningApproval or if the provided RequestID to CommissionNode does not match the value provided to RequestCommissioningApproval.

If the command is not executed via a CASE session, the command SHALL fail with a status code of UNSUPPORTED_ACCESS.

Upon receipt, the server SHALL respond with ReverseOpenCommissioningWindow if CommissioningRequestResult was generated with StatusCode of SUCCESS for the matching RequestID field and NodeID of the client.

The server SHALL return FAILURE if the CommissionNode command is received after the server has already responded to a client with ReverseOpenCommissioningWindow for a matching RequestID field and NodeID of the client unless the client has sent another RequestCommissioningApproval and received an additional CommissioningRequestResult.

The parameters for CommissionNode command are as follows:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	RequestID	uint64				M
1	Response-TimeoutSeconds	uint16	30 to 120		30	M

11.26.6.6. RequestID Field

This SHALL be set by the client to be the same value provided to RequestCommissioningApproval.

11.26.6.7. ResponseTimeoutSeconds Field

Timeout in seconds that the client SHALL wait to receive a response before considering the responses invalid.

11.26.6.8. ReverseOpenCommissioningWindow Command

When received within the timeout specified by ResponseTimeoutSeconds in the CommissionNode command, the client SHALL open a commissioning window on a node which matches the VendorID and ProductID provided in the associated RequestCommissioningApproval command.

When commissioning this node, the server SHALL check that the VendorID and ProductID fields provided in the RequestCommissioningApproval command match the VendorID and ProductID attributes of the Basic Information Cluster which have already been verified during the [Device Attestation Procedure](#). If they do not match, the server SHALL NOT complete commissioning and SHOULD indicate an error to the user.

NOTE

This is an alias onto the [OpenCommissioningWindow](#) command within the Admin-