

- Return the `TLSEndpointID` as the `EndpointID` field in the corresponding `ProvisionEndpointResponse` command.

General Notes When the Node is making a TLS connection to this TLS Endpoint, the `TLSRCAC` represented by the `CAID` SHALL be used to authenticate the TLS Endpoint.

When the Node is making a TLS connection that has a non-NULL `CCDID`, the Client Certificate Details represented by the `CCDID` SHALL be used during client authentication in the TLS Handshake. In addition, a Node SHALL fail to connect to the TLS server, if that TLS Server did not require TLS Client Authentication for the connection, when a `CCDID` is provisioned on a TLS Endpoint.

14.5.7.2. ProvisionEndpointResponse Command

This command is used to report the result of the `ProvisionEndpoint` command.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	EndpointID	TLSEndpointID	0 to 65534			M

EndpointID Field

This field SHALL be the TLS Endpoint ID created or updated by the `ProvisionEndpoint` command.

14.5.7.3. FindEndpoint Command

This command is used to find a TLS Endpoint by its ID.

This command SHALL return the `TLSEndpointStruct` for the passed in `EndpointID`.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	EndpointID	TLSEndpointID	0 to 65534			M

EndpointID Field

This field SHALL be the TLS Endpoint ID being looked up.

Effect on Receipt

The following process SHALL be followed when the server receives this command:

- If the `ProvisionedEndpoints` list is empty:
 - Fail the command with the status code `NOT_FOUND`, and end processing with no other side effects.
- If there is no matching entry found for the passed in `EndpointID` in the `ProvisionedEndpoints` list: