

This field SHALL be set to False for all other fabrics when an attribute with the Scenes ("S") designation in the Quality column of another cluster present on the same endpoint is modified or when the current scene is modified by a fabric through the [RecallScene](#) or [StoreScene](#) commands, regardless of the fabric-scoped access quality of the command.

In the event where the SceneValid field is set to False for a fabric, the CurrentScene and CurrentGroup fields SHALL be the last invoked scene and group for that fabric. In the event where no scene was previously invoked for that fabric, the CurrentScene and CurrentGroup fields SHALL be their default values.

1.4.7.2.5. RemainingCapacity Field

This field SHALL indicate the remaining capacity of the [Scene Table](#) on this endpoint for the accessing fabric. Note that this value may change between reads, even if no entries are added or deleted on the accessing fabric, due to other clients associated with other fabrics adding or deleting entries that impact the resource usage on the device.

1.4.7.3. AttributeValuePairStruct Type

This data type indicates a combination of an identifier and the value of an attribute.

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0	AttributeID	attrib-id	all				M
1	ValueUnsigned8	uint8					O.a
2	ValueSigned8	int8					O.a
3	ValueUnsigned16	uint16					O.a
4	ValueSigned16	int16					O.a
5	ValueUnsigned32	uint32					O.a
6	ValueSigned32	int32					O.a
7	ValueUnsigned64	uint64					O.a
8	ValueSigned64	int64					O.a

1.4.7.3.1. AttributeID Field

This field SHALL be present for all instances in a given [ExtensionFieldSetStruct](#).